

GAME	NOTES	GAME SELECTION DIP SWITCH S5											CPU CLOCK JUMPERS		RAM WIDTH S6
		COMBO ROM 08-20-19											.5Mhz	.895Mhz	D0-D4
BALLY -17	REPLACING BALLY AS-2518-17	DIP-1	DIP-2	DIP-3	DIP-4	DIP-5	DIP-6	DIP-7	DIP-8	DIP-8	B1	S1	DIP-1 TO DIP-4		
000	Black Jack	DIP 17, 18 & 19 ON for freeplay. Enhanced Switch Test	ON	ON	ON	ON	ON	ON	ON	ON	IN	OUT	OFF / OUT		
001	Eight Ball	DIP 17, 18 & 19 ON for freeplay. Enhanced Switch Test	ON	ON	ON	ON	ON	ON	ON	OFF	IN	OUT	OFF / OUT		
002	Evel Knivel	DIP 17, 18 & 19 ON for freeplay. Tilt exploit fixed. Drop target down logic.	ON	ON	ON	ON	ON	ON	OFF	ON	IN	OUT	OFF / OUT		
003	Freedom	DIP 17, 18 & 19 ON for freeplay. Tilt exploit fixed. Drop target down logic.	ON	ON	ON	ON	ON	ON	OFF	OFF	IN	OUT	OFF / OUT		
004	Mata Hari	DIP 17, 18 & 19 ON for freeplay. Drop target down logic.	ON	ON	ON	ON	ON	OFF	ON	ON	IN	OUT	OFF / OUT		
005	Night Rider	DIP 17, 18 & 19 ON for freeplay. Tilt exploit fixed. Drop target down logic.	ON	ON	ON	ON	ON	OFF	ON	OFF	IN	OUT	OFF / OUT		
006	Night Rider Custom	Home ROM by Seymour Shawob	ON	ON	ON	ON	ON	OFF	OFF	ON	IN	OUT	OFF / OUT		
007	Power Play	DIP 17, 18 & 19 ON for freeplay. Enhanced Switch Test	ON	ON	ON	ON	ON	OFF	OFF	OFF	IN	OUT	OFF / OUT		
008	Strikes and Spares	DIP 17, 18 & 19 ON for freeplay. Enhanced Switch Test	ON	ON	ON	ON	ON	OFF	ON	ON	IN	OUT	OFF / OUT		
BALLY -35	REPLACING BALLY AS-2518-35	DIP-1	DIP-2	DIP-3	DIP-4	DIP-5	DIP-6	DIP-7	DIP-8	DIP-8	B1	S1	DIP-1 TO DIP-4		
009	Black Pyramid	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	ON	OFF	IN	OUT	OFF / OUT		
010	BMX	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	OFF	ON	IN	OUT	OFF / OUT		
011	Centaur	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	OFF	OFF	IN	OUT	OFF / OUT		
012	Centaur Home	Home ROM by Oliver O.	ON	ON	ON	ON	OFF	OFF	ON	ON	IN	OUT	OFF / OUT		
013	Cybernaut	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	OFF	ON	OFF	IN	OUT	OFF / OUT		
014	Dolly	DIP 25 & 26 ON for freeplay. DIP21 ON for 7 digit display.	ON	ON	ON	ON	OFF	OFF	OFF	ON	IN	OUT	OFF / OUT		
015	Eight Ball Deluxe	DIP 25 & 26 ON for freeplay. Multiplayer bonus bug fixed.	ON	ON	ON	ON	OFF	OFF	OFF	OFF	IN	OUT	OFF / OUT		
016	Eight Ball Deluxe Home	Home ROM by Oliver O.	ON	ON	ON	ON	OFF	ON	ON	ON	IN	OUT	OFF / OUT		
017	Elektra	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	ON	ON	IN	OUT	OFF / OUT		
018	Embryon	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	ON	OFF	IN	OUT	OFF / OUT		
019	Embryon Home	Home ROM by Oliver O.	ON	ON	ON	ON	OFF	ON	ON	OFF	IN	OUT	OFF / OUT		
020	Fathom	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	OFF	ON	IN	OUT	OFF / OUT		
021	Fathom Home	Home ROM by Oliver O.	ON	ON	ON	ON	OFF	ON	OFF	ON	IN	OUT	OFF / OUT		
022	Fireball Classic	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	OFF	OFF	IN	OUT	OFF / OUT		
023	Fireball II	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	OFF	OFF	IN	OUT	OFF / OUT		
024	Flash Gordon	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	ON	ON	IN	OUT	OFF / OUT		
025	Flash Gordon French	DIP 25 & 26 ON for freeplay. French Language	ON	ON	ON	ON	OFF	OFF	ON	ON	IN	OUT	OFF / OUT		
026	Frontier	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	ON	OFF	IN	OUT	OFF / OUT		
027	Future Spa	DIP 25 & 26 ON for freeplay. DIP21 ON for 7 digit display.	ON	ON	ON	ON	OFF	ON	OFF	OFF	IN	OUT	OFF / OUT		
028	Harlem Globetrotters	DIP 25 & 26 ON for freeplay. DIP21 ON for 7 digit display.	ON	ON	ON	ON	OFF	OFF	OFF	ON	IN	OUT	OFF / OUT		
029	Holdoggin'	DIP 25 & 26 ON for freeplay. DIP27 OFF for reset letters at EOB	ON	ON	ON	ON	OFF	OFF	OFF	ON	IN	OUT	OFF / OUT		
030	Kings of Steel	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	OFF	OFF	ON	IN	OUT	OFF / OUT		
031	Kiss	DIP 17, 18 & 19 ON for freeplay	ON	ON	ON	ON	OFF	OFF	OFF	OFF	IN	OUT	OFF / OUT		
032	Kiss 7-Digit	7 Digit displays. No Freeplay.	ON	ON	ON	ON	ON	ON	ON	ON	IN	OUT	OFF / OUT		
033	Lost World	DIP 17, 18 & 19 ON for freeplay	ON	ON	ON	ON	ON	ON	ON	OFF	IN	OUT	OFF / OUT		
034	Medusa	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	ON	ON	OFF	ON	IN	OUT	OFF / OUT		
035	Mr and Mrs Pacman	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	ON	ON	OFF	OFF	IN	OUT	OFF / OUT		
036	Mystic	DIP 25 & 26 ON for freeplay. DIP21 ON for 7 digit display.	ON	ON	ON	ON	ON	OFF	ON	ON	IN	OUT	OFF / OUT		
037	Nitro Ground Shaker	DIP 25 & 26 ON for freeplay. DIP21 ON for 7 digit display.	ON	ON	ON	ON	ON	OFF	ON	OFF	IN	OUT	OFF / OUT		
038	Paragon	DIP 17, 18 & 19 ON for freeplay	ON	ON	ON	ON	ON	ON	OFF	ON	IN	OUT	OFF / OUT		
039	Paragon 7-Digit	7 Digit Displays. No Freeplay	ON	ON	ON	ON	ON	OFF	OFF	OFF	IN	OUT	OFF / OUT		
040	Playboy	DIP 17, 18 & 19 ON for freeplay	ON	ON	ON	ON	OFF	ON	ON	ON	IN	OUT	OFF / OUT		
041	Playboy 7-Digit	7 Digit Displays. No Freeplay	ON	ON	ON	ON	ON	ON	ON	ON	IN	OUT	OFF / OUT		
042	Rolling Stones	DIP 25 & 26 ON for freeplay. DIP21 ON for 7 digit display.	ON	ON	ON	ON	OFF	ON	OFF	ON	IN	OUT	OFF / OUT		
043	Silverball Mania	DIP 25 & 26 ON for freeplay. DIP21 ON for 7 digit display.	ON	ON	ON	ON	OFF	ON	OFF	OFF	IN	OUT	OFF / OUT		
044	Skateball	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	OFF	ON	IN	OUT	OFF / OUT		
045	Skateball Home	DIP 25 & 26 ON for freeplay. Improved attract mode lighting.	ON	ON	ON	ON	OFF	OFF	ON	OFF	IN	OUT	OFF / OUT		
046	Space Invaders	DIP 25 & 26 ON for freeplay. DIP21 ON for 7 digit display.	ON	ON	ON	ON	OFF	ON	OFF	OFF	IN	OUT	OFF / OUT		
047	Speakeasy 4 Player	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	OFF	OFF	IN	OUT	OFF / OUT		
048	Speakeasy 2 Player	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	ON	ON	IN	OUT	OFF / OUT		
049	Spectrum	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	ON	ON	ON	IN	OUT	OFF / OUT		
050	Spectrum Home	Home ROM by Oliver O.	ON	ON	ON	ON	OFF	ON	ON	OFF	IN	OUT	OFF / OUT		
051	Spy Hunter	DIP 25 & 26 ON for freeplay.	ON	ON	ON	ON	OFF	ON	ON	OFF	IN	OUT	OFF / OUT		
052	Star Trek	DIP 17, 18 & 19 ON for freeplay	ON	ON	ON	ON	OFF	ON	ON	ON	IN	OUT	OFF / OUT		
053	Star Trek	7 Digit Displays. No Freeplay	ON	ON	ON	ON	OFF	ON	OFF	ON	IN	OUT	OFF / OUT		
054	Supersonic	DIP 17, 18 & 19 ON for freeplay	ON	ON	ON	ON	OFF	ON	OFF	OFF	IN	OUT	OFF / OUT		
055	Supersonic	7 Digit Displays. No Freeplay	ON	ON	ON	ON	OFF	ON	OFF	OFF	IN	OUT	OFF / OUT		
056	The Six Million Dollar Man	DIP 17, 18 & 19 ON for freeplay. DIP31 must be OFF.	ON	ON	ON	ON	OFF	OFF	ON	ON	IN	OUT	OFF / OUT		
057	The Six Million Dollar Man	7 Digit Displays. No Freeplay	ON	ON	ON	ON	OFF	OFF	ON	ON	IN	OUT	OFF / OUT		
058	Vector	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	OFF	ON	OFF	IN	OUT	OFF / OUT		
059	Vector Home	Home ROM by Oliver O.	ON	ON	ON	ON	OFF	OFF	ON	OFF	IN	OUT	OFF / OUT		
060	Viking	DIP 25 & 26 ON for freeplay. DIP21 ON for 7 digit display.	ON	ON	ON	ON	OFF	OFF	ON	ON	IN	OUT	OFF / OUT		
061	Voltan Escapes Cosmic Doom	DIP 17, 18 & 19 ON for freeplay	ON	ON	ON	ON	OFF	OFF	OFF	ON	IN	OUT	OFF / OUT		
062	Voltan Escapes Cosmic Doom	7 Digit Displays. No Freeplay	ON	ON	ON	ON	OFF	OFF	OFF	OFF	IN	OUT	OFF / OUT		
063	X's and O's	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	OFF	OFF	OFF	OFF	IN	OUT	OFF / OUT		
064	Xenon	DIP 25 & 26 ON for freeplay	ON	ON	ON	ON	ON	ON	ON	ON	IN	OUT	OFF / OUT		
STERN MPU-100	REPLACING STERN MPU-100	DIP-1	DIP-2	DIP-3	DIP-4	DIP-5	DIP-6	DIP-7	DIP-8	DIP-8	B1	S1	DIP-1 TO DIP-4		
065	Cosmic Princess	DIP 20 ON for Freeplay. Credit Display Always On.	ON	OFF	ON	ON	ON	ON	ON	OFF	IN	OUT	OFF / OUT		
066	Dracula	DIP 20 ON for Freeplay. Credit Display Always On.	ON	OFF	ON	ON	ON	ON	OFF	ON	IN	OUT	OFF / OUT		
067	Hot Hand	DIP 20 ON for Freeplay. Credit Display Always On.	ON	OFF	ON	ON	ON	ON	OFF	OFF	IN	OUT	OFF / OUT		
068	Lectronamo	DIP 20 ON for Freeplay. Credit Display Always On.	ON	OFF	ON	ON	ON	OFF	ON	ON	IN	OUT	OFF / OUT		
069	Memory Lane	DIP 20 ON for Freeplay. Credit Display Always On.	ON	OFF	ON	ON	ON	OFF	ON	OFF	IN	OUT	OFF / OUT		
070	Nugent	Same ROM as Lectronamo	ON	OFF	ON	ON	ON	OFF	ON	ON	IN	OUT	OFF / OUT		
070	Pinball	DIP 20 ON for Freeplay. Credit Display Always On.	ON	OFF	ON	ON	ON	OFF	OFF	ON	IN	OUT	OFF / OUT		
071	Stars	DIP 20 ON for Freeplay. Credit Display Always On.	ON	OFF	ON	ON	ON	OFF	OFF	OFF	IN	OUT	OFF / OUT		
070	Stingray	Same ROM as Pinball	ON	OFF	ON	ON	ON	OFF	OFF	ON	IN	OUT	OFF / OUT		
072	Trident	Factory Modified ROM P11A. Unknown changes. No Freeplay.	ON	OFF	ON	ON	ON	ON	ON	ON	IN	OUT	OFF / OUT		
073	Trident	DIP 20 ON for Freeplay. Credit Display Always On.	ON	OFF	ON	ON	ON	ON	ON	OFF	IN	OUT	OFF / OUT		
066	Wild Fyre	Same ROM as Dracula	ON	OFF	ON	ON	ON	ON	OFF	ON	IN	OUT	OFF / OUT		
STERN MPU-200 **	REPLACING STERN MPU-200	DIP-1	DIP-2	DIP-3	DIP-4	DIP-5	DIP-6	DIP-7	DIP-8	DIP-8	B1	S1	DIP-1 TO DIP-4		
074	Ali	Stock ROM. No Freeplay	ON	OFF	ON	ON	ON	ON	OFF	ON	ON	IN	ON / IN		
075	Ali	Always Freeplay	ON	OFF	ON	ON	ON	OFF	ON	OFF	OUT	IN	ON / IN		
076	Big Game	Stock ROM. No Freeplay	ON	OFF	ON	ON	ON	OFF	ON	ON	ON	IN	ON / IN		
077	Big Game	Always Freeplay	ON	OFF	ON	ON	ON	OFF	ON	OFF	OUT	IN	ON / IN		
078	Catacomb	Stock ROM. No Freeplay	ON	OFF	ON	ON	ON	OFF	OFF	ON	OUT	IN	ON / IN		
079	Catacomb	Always Freeplay	ON	OFF	ON	ON	ON	OFF	OFF	OFF	OUT	IN	ON / IN		

GAME	NOTES	GAME SELECTION DIP SWITCH S5								CPU CLOCK JUMPERS		RAM WIDTH S6
		A20	A19	A18	A17	A16	A15	A14	A13	.5Mhz	.895Mhz	D0-D4
STERN MPU-200 **	REPLACING STERN MPU-200	DIP-1	DIP-2	DIP-3	DIP-4	DIP-5	DIP-6	DIP-7	DIP-8	B1	S1	DIP-1 TO DIP-4
080	Cheetah	ON	OFF	ON	OFF	ON	ON	ON	ON	OUT	IN	ON / IN
081	Cheetah	ON	OFF	ON	OFF	ON	ON	ON	OFF	OUT	IN	ON / IN
082	Cheetah	ON	OFF	ON	OFF	ON	ON	OFF	ON	OUT	IN	ON / IN
083	Cheetah Home	ON	OFF	ON	OFF	ON	ON	OFF	OFF	OUT	IN	ON / IN
084	Dragonfist	ON	OFF	ON	OFF	ON	OFF	ON	ON	OUT	IN	ON / IN
085	Dragonfist	ON	OFF	ON	OFF	ON	OFF	ON	OFF	OUT	IN	ON / IN
086	Dragonfist Home	ON	OFF	ON	OFF	ON	OFF	OFF	ON	OUT	IN	ON / IN
087	Flight 2000	ON	OFF	ON	OFF	ON	OFF	OFF	OFF	OUT	IN	ON / IN
088	Flight 2000	ON	OFF	ON	OFF	ON	OFF	ON	ON	OUT	IN	ON / IN
089	Freefall	ON	OFF	ON	OFF	OFF	ON	ON	OFF	OUT	IN	ON / IN
090	Freefall	ON	OFF	ON	OFF	OFF	ON	OFF	ON	OUT	IN	ON / IN
091	Galaxy	ON	OFF	ON	OFF	OFF	ON	OFF	OFF	OUT	IN	ON / IN
092	Galaxy	ON	OFF	ON	OFF	OFF	OFF	ON	ON	OUT	IN	ON / IN
093	Iron Maiden	ON	OFF	ON	OFF	OFF	OFF	ON	OFF	OUT	IN	ON / IN
094	Iron Maiden	ON	OFF	ON	OFF	OFF	OFF	OFF	ON	OUT	IN	ON / IN
095	Lightning	ON	OFF	ON	OFF	OFF	OFF	OFF	OFF	OUT	IN	ON / IN
096	Lightning	ON	OFF	OFF	ON	ON	ON	ON	ON	OUT	IN	ON / IN
097	Meteor	ON	OFF	OFF	ON	ON	ON	ON	OFF	OUT	IN	ON / IN
098	Meteor 7 Digit	ON	OFF	OFF	ON	ON	ON	OFF	ON	OUT	IN	ON / IN
099	Meteor Divide by 10	ON	OFF	OFF	ON	ON	ON	OFF	OFF	OUT	IN	ON / IN
100	Meteor Free	ON	OFF	OFF	ON	ON	OFF	ON	ON	OUT	IN	ON / IN
101	Nine Ball	ON	OFF	OFF	ON	ON	OFF	ON	OFF	OUT	IN	ON / IN
102	Nine Ball	ON	OFF	OFF	ON	ON	OFF	OFF	ON	OUT	IN	ON / IN
103	Orbitor One	ON	OFF	OFF	ON	ON	OFF	OFF	OFF	OUT	IN	ON / IN
104	Orbitor One	ON	OFF	OFF	ON	OFF	ON	ON	ON	OUT	IN	ON / IN
105	Orbitor One	ON	OFF	OFF	ON	OFF	ON	ON	OFF	OUT	IN	ON / IN
106	Quicksilver	ON	OFF	OFF	ON	OFF	ON	OFF	ON	OUT	IN	ON / IN
107	Quicksilver	ON	OFF	OFF	ON	OFF	ON	OFF	OFF	OUT	IN	ON / IN
108	Seawitch	ON	OFF	OFF	ON	OFF	OFF	ON	ON	OUT	IN	ON / IN
109	Seawitch	ON	OFF	OFF	ON	OFF	OFF	ON	OFF	OUT	IN	ON / IN
110	Split Second	ON	OFF	OFF	ON	OFF	OFF	OFF	ON	OUT	IN	ON / IN
111	Split Second	ON	OFF	OFF	ON	OFF	OFF	OFF	OFF	OUT	IN	ON / IN
112	Star Gazer	ON	OFF	OFF	OFF	ON	ON	ON	ON	OUT	IN	ON / IN
113	Star Gazer	ON	OFF	OFF	OFF	ON	ON	ON	OFF	OUT	IN	ON / IN
114	Star Gazer Home	ON	OFF	OFF	OFF	ON	ON	OFF	ON	OUT	IN	ON / IN
129	Star Gazer Seymour Home V6	OFF	ON	ON	ON	ON	ON	ON	OFF	OUT	IN	ON / IN
115	Viper	ON	OFF	OFF	OFF	ON	ON	OFF	OFF	OUT	IN	ON / IN
116	Viper	ON	OFF	OFF	OFF	ON	OFF	ON	ON	OUT	IN	ON / IN
Bally Video and Special	REPLACING AS-2518-133 and Conversion Kits	DIP-1	DIP-2	DIP-3	DIP-4	DIP-5	DIP-6	DIP-7	DIP-8	B1	S1	DIP-1 TO DIP-4
117	Baby Pacman	ON	OFF	OFF	OFF	ON	OFF	ON	OFF	IN	OUT	OFF / OUT
118	Granny and the Gators	ON	OFF	OFF	OFF	ON	OFF	OFF	ON	IN	OUT	OFF / OUT
119	Grand Slam 2 Player	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF	IN	OUT	OFF / OUT
120	Grand Slam 4 Player	ON	OFF	OFF	OFF	OFF	ON	ON	ON	IN	OUT	OFF / OUT
121	Goldball	ON	OFF	OFF	OFF	OFF	ON	ON	OFF	IN	OUT	OFF / OUT
122	Goldball Home	ON	OFF	OFF	OFF	OFF	ON	OFF	ON	IN	OUT	OFF / OUT
123	Mystic Star	ON	OFF	OFF	OFF	OFF	ON	OFF	OFF	IN	OUT	OFF / OUT
124	World Defender	ON	OFF	OFF	OFF	OFF	OFF	ON	ON	IN	OUT	OFF / OUT
125	Super Bowl	ON	OFF	OFF	OFF	OFF	OFF	ON	OFF	IN	OUT	OFF / OUT
126	Super Bowl	ON	OFF	OFF	OFF	OFF	OFF	OFF	ON	IN	OUT	OFF / OUT
127	Saturn 2	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	IN	OUT	OFF / OUT
128	Midnight Mauraders	OFF	ON	ON	ON	ON	ON	ON	ON	IN	OUT	OFF / OUT
130	Rapid Fire	OFF	ON	ON	ON	ON	ON	OFF	ON	IN	OUT	OFF / OUT
254	MEMORY CLEAR **	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	EITHER B1 OR S1 IN		ON / IN

NOTES:

RAM width may be zero ohm jumper shunts(OUT / IN) or a DIP switch (OFF / ON). IN / ON for MPU200 only.

B1 and S1 jumpers set the CPU clock speed. B IN for 0.5MHz (Bally -17, -35, -133 and Stern MPU-100). S IN for 0.895MHz (Stern MPU-200)

Jumper shunt U2 Enable is removed when the U1 expanded ROM socket is used.

Clear audits with the Test and NMI Audit Clear buttons after switching games.

Starting in Revision 14 the game select dip switch is orientated so UP is on and DOWN is off.

** If you experience wrong sounds running in a Stern MPU200 game use the MEMORY CLEAR software (DEC # 254). Power up and when the LED begins to blink the memory has been cleared.

MPU Setup pictures at <http://nvram.weebly.com/mpu.html>